Sprinkler Service Tools

Residential/Commercial

Part No.	Description
	570 SERIES
89-6395	Riser Pull Up Tool
‡89-7350	Adjustment Key
	570Z PRX SERIES
102-1777	X-tool
	S700 SERIES
89-1375	Nozzle Tool & Wrench
	2001 SERIES
‡89-4717	Adjustment Tool
995-83	Multi-purpose Tool
	S606 SERIES
995-58	Nozzle Tool Kit
	640 SERIES
995-07	Snap Ring Pliers
995-08	Valve Removal Tool
995-35	Valve Insertion Tool
995-37	Seal Installation Tool
995-42	Nozzle Canister Removal Tool
995-46	Cap Removal Tool
	740 SERIES
995-07	Valve Snap Ring Pliers
995-08	Valve Removal Tool
995-52	Nut Driver, 1/4"
995-53	Nut Driver, 3/8"
995-55	Riser Hold Up Tool
995-76	Valve Insertion Tool
996-06	Snap Ring Removal Tool
995-83	Multi-purpose Tool
	V-1550 SERIES
995-83	Multi-purpose Tool
‡89-7350	Adjustment Key

‡ Order through Parts Distribution System.
All other tools listed order through Finished Goods Distribution System - Minneapolis.

Golf, 1 Inch Body

Part No.	Description
	ALL MODELS
	(630, 660, 730, 760)
995-07	Valve Snap Ring Pliers
995-08	Valve Removal Tool
995-15	Selector Tool Flag Key)
995-49	Pressure Gauge
995-50	Pitot Tube
995-51	Pressure Gauge Kit (Includes 995-49 & 995-50)
995-76	Valve Insertion Tool
	630 SERIES
995-06	Drive Assy. Extraction Tool
995-16	Riser Pliers
995-31	Hose Adapter
	660 SERIES
995-52	Nut Driver, 1/4"
995-53	Nut Driver, 3/8"
995-55	Riser Hold Up Tool
995-83	Multi-purpose Tool
	730 SERIES
995-55	Riser Hold Up Tool
995-83	Multi-purpose Tool
995-84	Riser Removal Tool
	760 SERIES
995-55	Riser Hold Up Tool
995-79	Nut Driver, 7/16" (For Inner Nozzle)
995-80	Nut Driver, 1/2" (For 363-3137 Jam Nut)
995-81	Nut Driver, 9/16" (For Main Nozzle)
995-82	Arc Adjustment Tool, 3/32" (T-handle Hex Wrench)
995-83	Multi-purpose Tool
995-84	Riser Removal Tool

Golf, 1.5 Inch Body

Part No.	Description
	ALL MODELS
	(650, 670, 680, 750, 780)
995-07	Valve Snap Ring Pliers
995-09	Valve Removal Tool
995-10	Valve Insertion Tool
995-15	Selector Tool (Flag Key)
995-49	Pressure Gauge
995-50	Pitot Tube
995-51	Pressure Gauge Kit (Includes 995-49 & 995-50)
	650 SERIES
995-06	Drive Assy. Extraction Tool
995-07	Valve Snap Ring Pliers
995-16	Riser Pliers
995-31	Hose Adapter
995-79	Nut Driver 7/16" (For Inner Nozzle)
	670 SERIES
995-07	Valve Snap Ring Pliers
	680 SERIES
995-52	Nut Driver, 1/4"
995-53	Nut Driver, 3/8"
995-55	Riser Hold Up Tool
995-83	Multi-purpose Tool
	750 SERIES
995-55	Riser Hold Up Tool
995-83	Multi-purpose Tool
995-84	Riser Removal Tool
	780 SERIES
995-55	Riser Hold Up Tool
995-79	Nut Driver, 7/16" (For Inner Nozzle)
995-80	Nut Driver, 1/2" (For 363-3137 Jam Nut)
995-81	Nut Driver, 9/16" (For Main Nozzle)
995-82	Arc Adjustment Tool, 3/32" (T-handle Hex Wrench)
995-83	Multi-purpose Tool
995-84	Riser Removal Tool

690 Series

Part No.	Description
995-06	Drive Assy. Extraction Tool
995-07	Valve Snap Ring Pliers
995-09	Valve Removal Tool
995-12	Valve Insertion Tool
995-15	Selector Tool (Flag Key)
995-17	Riser Pliers
995-20	Valve Insertion Tool, Rubber Cover
995-22	Hose Adapter
995-49	Pressure Gauge
995-50	Pitot Tube
995-51	Pressure Gauge Kit (Includes 995-49 & 995-50)